Samba Maracas

USER'S GUIDE

for Wii™

Package Contents

- 2 Maraca extensions
- 2 Remote cradles
- 1 Nunchuck cradle

dreamGEAR®
www.dreamgear.net

SET-UP INSTRUCTIONS:

1. Each Maraca requires 2 “AAA” batteries for powering the LEDs. Remove the battery lid on each Maraca and install 2 “AAA” batteries into each Maraca, replace battery lids. Batteries are only required for the LED feature. The Maracas can be used with or without batteries.

2. To attach the Wii Remote/Nunchuck cradle to the Maraca extension, align the pegs located on top of the cradle with the slots located on the bottom of the Maraca extension.

3. Slide the cradle into the Maraca extension.

4. Turn the cradle clockwise and lock into place.

5. Slide the Wii Remote/Nunchuck into the cradle.

6. To detach the Wii Remote/Nunchuck cradle from the Maraca extension, slide down the latch located on top of the Remote/Nunchuck cradle, turn the cradle counter-clockwise and remove.

GAME PLAY: The Samba Maracas include 2 Wii Remote extensions and 1 Nunchuck extension. The Samba De Amiga game provides 2 options for playing the game. When playing Samba De Amiga you can play with 2 Wii Remotes or 1 Wii Remote and 1 Nunchuck. The choice is yours.

Note: *Always practice safety first. Make sure the Wii Remote/Nunchuck cradle is* ***attached properly and securely*** *to the Pom Pom extension. Be aware of your surroundings and stay a safe distance from all objects. Don’t ever swing your Pom Poms at anyone or anything.*

DISCLAIMER: *dreamGEAR is NOT liable for any direct, indirect, punitive, incidental, special, consequential damages, or any damages whatsoever arising out of or connected with the use or misuse of this Product.*

FOR TECHNICAL SUPPORT
PLEASE CONTACT: 1-877-999-DREAM
or support@dreamgear.net